



Where modular joints are placed in the roadway, the following will apply:

1. The \mathcal{C} of the support box will not be less than 230 mm nor more than 300 mm from the construction joint.
2. The elastomeric seal will be one piece across the roadway width and will not be spliced at the construction joint.
3. Where practical, a modular joint should be a one-piece rail across the roadway width.

MODULAR EXPANSION JOINT (Field Splice)

Figure 61-4 I